

1. REMOVE CANOPY COVER PLATE FROM CANOPY ASSEMBLY, LETTING HANG FROM SAFETY CABLES
2. ALIGN CANOPY TO ITS MOUNTING LOCATION - THE CENTER SHOULD LINE UP WITH THE J-BOX IN THE BUILDING STRUCTURE - **NOTE: THE OUTER EDGES OF THE CANOPY DO NOT NEED TO MOUNT TO A STUD, AS DRYWALL TOGGLE BOLTS WILL BE USED**
3. MOUNT THE CENTER OF THE CANOPY TO THE BUILDING STRUCTURE USING 1/4" LAG BOLTS
4. ENSURE THE ORIENTATION IS AS DESIRED, AND INSTALL THE TOGGLE BOLTS
5. TEMPORARILY RE-ATTACH THE MAGNETIC CANOPY COVER PLATES
6. **NOTE: PERFORM STEPS 6-7 ON ONE PENDANT ASSEMBLY ONLY** - ASSEMBLE THE TOTEM BY SLIDING PIECES INTO PLACE AS SHOWN ON NEXT PAGE, SECURING EACH END BY SCREWING ON END CAPS (ASSEMBLY WRENCH PROVIDED).
NOTE: SLIDE UPPER ACCENT TUBE, END CAP, AND CHECK RINGS ONTO THE SOLIMAR CABLE, AS SHOWN
7. CUT THE SOLIMAR CABLE TO THE DESIRED LENGTH, FEED THROUGH THE HOLES IN THE CANOPY, AND ATTACH THE UPPER GRIPPER TO THE CANOPY ASSEMBLY
8. **REPEAT STEPS 6-7 FOR ALL THREE PENDANT ASSEMBLIES**
9. MAKE ELECTRICAL CONNECTIONS
10. RE-ATTACH CANOPY COVER PLATES



SOLIMAR INSTALL



