

1. REMOVE CANOPY COVER PLATE FROM CANOPY ASSEMBLY
2. ALIGN CANOPY TO ITS MOUNTING LOCATION - THE CENTER SHOULD LINE UP WITH THE J-BOX IN THE BUILDING STRUCTURE
3. MOUNT THE CANOPY TO THE J-BOX USING PROVIDED 8-32 SCREWS
4. TEMPORARILY RE-ATTACH THE MAGNETIC CANOPY COVER PLATE
5. ASSEMBLE THE TOTEM BY SLIDING PIECES INTO PLACE AS SHOWN ON NEXT PAGE, SECURING EACH END BY SCREWING ON END CAPS (ASSEMBLY WRENCH PROVIDED). **NOTE: SLIDE UPPER ACCENT TUBE, END CAP, AND CHECK RINGS ONTO THE SOLIMAR CABLE, AS SHOWN**
6. CUT THE SOLIMAR CABLE TO THE DESIRED LENGTH, FEED THROUGH THE HOLE IN THE CANOPY, AND ATTACH THE UPPER GRIPPER TO THE CANOPY ASSEMBLY
7. MAKE ELECTRICAL CONNECTIONS
8. RE-ATTACH MAGNETIC CANOPY COVER PLATE

