

1. REMOVE CANOPY COVER PLATE
2. MOUNT CANOPY TO CEILING WITH SUPPLIED HARDWARE (LAG SCREWS)
3. PASS END OF AIRCRAFT CABLE THROUGH CABLE GRIPPER IN CANOPY, ADJUST TO HEIGHT DESIRED, AND SECURE CABLE WITH CABLE GRIPPERS TIGHTLY
4. PASS POWER CABLE THROUGH WIREWAY HOLE IN BOTTOM SURFACE OF CANOPY
5. MAKE ELECTRICAL CONNECTIONS BETWEEN LIGHT BODY AND LED DRIVER
6. TIE POWER CABLE TO ADJACENT AIRCRAFT CABLE WITH SUPPLIED SHRINK WRAP OR OTHER METHOD IF PREFERRED
7. REPLACE CANOPY COVER PLATE
8. GLASS CAN BE RE-ARRANGED BUT TAKE CARE NOT TO UNTHREAD LED MOUNT FROM LIGHT BODY AS WIRE DAMAGE CAN OCCUR

